

Putting new code into Intercom keypad

Turn handset off by holding down red call button until screen is blank and take handset to gate unit

- 1. Press the green call button and red call button together for 2 seconds until screen shows 3 dashes - -
- 2. Type *168 into gate unit keypad (sound "Di Di")
- 3. Type in new code slowly on the gate unit (more than 1 second between each number entry but less than 10 seconds) and as each number is pressed it should show on the handset screen Note the screen only shows 3 of the 4 numbers.
- 4. Long press red call button to switch the handset off to lock code in.

TEST using the keypad on the gate based unit.

Type *# before the selected code. "Di Di " should sound after a correct entry and the gate should open.